

IMPORTANT INFORMATION

KEEP THIS CARD
IN A SAFE PLACE



CALOR

**Are your flexible
LPG gas hoses in
poor condition or
more than 5 years
old?**

**Be smart and be
safe with Calor Gas**

Maintenance of Flexible Hose

Calor Gas cylinders and cylinder valves remain the property of Calor Teoranta who will carry out all necessary cylinder maintenance and testing. The pressure regulator change-over valve unit and associated cylinder hoses is your property together with the gas distribution system and all the gas appliances you operate. Calor Gas recommend that you have your gas pipework and appliances inspected and serviced at least once a year in order to keep them safe and running efficiently. This is especially important for any gas installation which involves buried pipework.

Calor recommend that:

- All flexible hoses should be replaced after 5 years of service or if showing signs of wear or damage.

INSPECT THEM FREQUENTLY

- Make sure hoses are kept clear of heat spots.
- Use only hose approved for use with Calor Gas.
- Keep hose length as short as practically possible.
- All flexible hoses and pipework should be secured as follows:

For 8mm internal diameter or greater operating at 50mbar or less then crimp clips, swaged fittings or worm drive clips can be used.

Worm drive clips should **not** be used for hose or tubing less than 8mm internal diameter and hose operating at greater than 50mbar.

- For further information on using butane and propane safely visit calorgas.ie

REMEMBER: Maintenance is essential to ensure your Calor installation is safe. Calor will always be pleased to offer advice.

Emergencies

In the event of an emergency or if you smell gas:

- Turn off supply at tank, cylinder or meter
- Turn off all gas appliances
- Open all doors and windows
- Do not touch any electrical plug/light switches
- Do not smoke or use naked flames

Emergency Telephone Numbers

Day Telephone: 1850 812 450

Outside Office Hours: 01 291 6229

Calor Gas
Longmile Road
Dublin 12

